

HD48... SERIES, HD 49... SERIES



HD48...SERIES, HD49...SERIES PASSIVE OR ACTIVE TRANSMITTERS TEMPERATURE, RELATIVE HUMIDITY AND TEMPERATURE, DEW POINT AND TEMPERATURE

HD48... and **HD49...** series of transmitters measure temperature, relative humidity and the dew point temperature.

Versions with only standard analog output or with only RS485 output with MODBUS- RTU protocol are available. The models with analog output provide a signal suitable for transmission to a remote display, recorder or PLC. The models with RS485 output are suitable for connection to a PC or PLC.

The models of the **HD48...** series are active transmitters and accept both direct and 24Vac alternating power supply; they have standard current (4...20 mA) or voltage (0...10V) outputs, or a serial RS485 output, depending on the model. The models of the **HD49...** series are passive transmitters and thus suitable to be inserted in a 4...20 mA current loop.

Both series of transmitters are designed for temperature and humidity control in conditioning and ventilation applications (HVAC/BEMS) in the following sectors: pharmacy, museums, clean rooms, ventilation ducts, industrial and civil sectors, crowded places, canteens, auditoria, gyms, high-density farms, greenhouses, etc.

The transmitters measure relative humidity with a well proven temperature compensated capacitive sensor that assures precise and reliable measurements in the course of time. Both HD48... and HD49... series are available in two probe temperature ranges: standard -20...+80 °C and extended -40...+150 °C for the most critical applications.

A stainless steel 10 μ m filter protects the sensors against dust and particles (other filters are available for different applications).

The transmitters are factory calibrated and no further adjustments are required.

Each series is available in different versions:

- with horizontal probe for duct mounting (HD48...TO..., HD49... TO...),
- with vertical probe for wall mounting (HD48...TV..., HD49...TV...);
- with remote probe connected to the transmitter by means of a cable (HD48...TC..., HD49...TC...). Cable lengths available are 2, 5 and 10 m.

The probes can be supplied in two different lengths: 135 mm or 335 mm.

Various accessories are available for the installation: for example to fix the probe to the duct, it can be used the HD9008.31 flange, a ¾" universal biconical connection or a PG16 metal cable gland (Ø 10...14 mm). A 4-digit optional display ("L" model) allows to display the measured parameters in a continuous or sequential mode.

Technical specifications	;				
	STAND	EXTENDED RANGE			
Relative Humidity					
Sensor	Capacitive				
Measuring range	0100 %RH				
Accuracy @T=1535℃	±1.5 %RH (()90 %RH), ±2.0 %R	H (90100 %RH)		
Accuracy @ rest of T range	±(1	.5+1.5% of the meas	ure) %RH		
Repeatability		0.4 %RH			
Sensor working temperature	-20	+80 ℃	-40+150 °C		
Temperature					
Measuring range	-20	+80 ℃	-40+150°C		
Sensor	N.	TC 10kΩ	Pt100 class A		
Accuracy	±0.3 °C ±0.4 °C (-20	(0+70 °C) .0 °C, +70+80 °C)	±0.3 ℃		
Repeatability		0.05 ℃	0.05 ℃		
Dew Point	_				
Sensor	Parameter	calculated from relat temperature	ive humidity and		
Measuring range		-20+80 °C DF			
Accuracy		See table 1			
Repeatability		0.5 °C DP			
Type of output (accordi	ng to the mode	el)			
HD 4807 T	Temperature	420 mA (-20+80 °C), R_L < 500Ω 22 mA outside the measuring range			
HD 4807E T	Temperature	420 mA (-40+150 °C), R _L < 500Ω 22 mA outside the measuring range			
HD 48V07 T	Temperature	010Vdc (-20+80 °C), R _L > $10 \text{k}\Omega$ 11 Vdc outside the measuring range			
HD 48V07E T	Temperature	010 Vdc (-40+150 °C), R _L > 10kC 11 Vdc outside the measuring range			
HD 48S07 T HD 48S07E T	Temperature	Only RS485 with MODBUS-RTU protocol			
HD 4907 T	Temperature	420 mA (-20+80 °C), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range			
HD 4907E T	Temperature	420 mA (-40+150 °C), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range			
HD 4801 T HD 4801E T	Relative Humidity	420 mA (0100 %RH), R _L $<$ 500 Ω 22 mA outside the measuring range			
HD 48V01 T HD 48V01E T	Relative Humidity	010Vdc (0100n %RH), $ \text{R}_{\text{L}} > 10 \text{k}\Omega$ 11 Vdc outside the measuring range			
HD 48S01 T HD 48S01E T	Relative Humidity	Only RS485 with MODBUS-RTU protocol			
HD 4901 T HD 4901E T	Relative Humidity	420 mA (0100 %RH), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range			
UD4017T	Relative Humidity	420 mA (010	0 %RH), R_L < 500Ω e measuring range		
HD 4817 T	Temperature $420 \text{ mA} (-20+80 ^{\circ}\text{C}), R_{L} < 500$				

22 mA outside the measuring range

LID4017FT	Relative Humidity	420 mA (0100 %RH), $R_L < 500\Omega$ 22 mA outside the measuring range	
HD 4817E T	Temperature	420 mA (- $40+150$ °C), $R_L < 500\Omega$ 22 mA outside the measuring range	
HD 48V17 T	Relative Humidity	11 Vdc outside the measuring range	
11040171	Temperature	010Vdc (-20+80 °C), $R_L > 10\text{k}\Omega$ 11 Vdc outside the measuring range	
HD 48V17E T	Relative Humidity	010Vdc (0100 %RH), $R_L > 10\text{k}\Omega$ 11 Vdc outside the measuring range	
11D46V17L1	Temperature	010Vdc (-40+150 °C), $R_L > 10 \text{k}\Omega$ 11 Vdc outside the measuring range	
HD48S17T	Relative Humidity	Only RS485 with MODBUS-RTU protocol	
HD 48S17E T	Temperature	,	
HD 4917 T	Relative Humidity	420 mA (0100 %RH), R_{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range	
HD 4917 1	Temperature	420 mA (-20+80 °C), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range	
LID 4017FT	Relative Humidity	420 mA (0100 %RH), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range	
HD 4917E T	Temperature	420 mA (-40+150 °C), R _{Lmax} = (Vdc-12)/0.022 22 mA outside the measuring range	
LID 4077T	Dew Point	420 mA (-20+80 °C DP), R_L < 500Ω 22 mA outside the measuring range	
HD 4877 T	Temperature	420 mA (-20+80 °C), R_L < 500 Ω 22 mA outside the measuring range	
HD48V77T	Dew Point	010 Vdc (-20+80 °C DP), $R_L > 10 k\Omega$ 11 Vdc outside the measuring range	
	Temperature	010Vdc (-20+80 °C), $R_L > 10\text{k}\Omega$ 11V dc outside the measuring range	
HD 48S77 T	Dew Point	Only RS485 with MODBUS-RTU protocol	
	Temperature	Chry 15-65 with Wobbos 110 plotocol	
HD 4977 T	Dew Point	420 mA (-20+80 °C DP), R _{t max} = (Vdc-12)/0.022 22 mA outside the measuring range	
1577	Temperature	420 mA (-20+80 °C), $R_{L_{max}} = (Vdc-12)/0.022$ 22mA outside the measuring range	


	electrical connections			
	HD48	HD49		
Power supply	1840 Vdc or 24 Vac ±10%	1240 Vdc		
. orre. supp.)	1230 Vdc for MODBUS output	1210 vae		
Consumption	- 4 mA@24V(models with voltage output) - 4 mA@24V with open output, 20 mA@24V with 12 mA output (models with current output) - 2 mA@24V models with serial RS485 output			
Electrical connections	Screw type terminal block, M16 cable gland for in	max 1,5mm², put cable		
General characteri	stics			
Standard filter	PBT and 10 µm stainless steel grid protection (P8), 20 µm PTFE (P7) only for extended range			
TV probe working temperature	-20…+80 ℃			
TO,TC Probes	STANDARD RANGE	EXTENDED RANGE		
working temperature	-20+80 °C	-40+150°C		
Electronics working temperature	-20+60 ℃			
Storage temperature	-20+80℃			
Electronics protection class	IP66			
Materials	ABS, polycarbonate			
Weight	from approx. 120 gr. (TV) to approx. 900 gr. (TC2.10)			
Case dimensions	80 x 84 x 44 (lenght x width x height)			

Table 1 - Accuracy of dew point measurement:

			°C DP							
		-20	-10	0	10	20	30	40	60	80
	-20	≤±1		_						
Ų	-10	≤±1	≤±1							
	0	≤±1	≤±1	≤±1			DPIIN	uт		
Temperature	10	≤± 3	≤±1	<±1	≤±1		DP LIIV	111		
irat	20	≤±4	≤±2	<±1	≤±1	<±1				
) de	30		≤± 3	≤±1,5	≤±1	<±1	≤±1			
e.	40				≤±2	<±1	≤±1	<±1		
-	60	NOT	SPECIF	FIED	≤± 5	≤±2,5	≤±2	≤±1	≤±1	
	80						≤±4	≤ ± 2	≤±1	≤±1

Installation notes

To fix the probe inside a ventilation duct, a pipe, etc., use for example the HD9008.31 flange, a PG16 metal cable gland (\emptyset 10...14mm) or a %" universal biconical connection.




Electrical connections

HD48... series with analog output


Power the instrument as shown in the below connection schemes, the power supply terminals are marked as +Vcc and GND. Depending on the model, the output signal is available between:

- Ta and AGND terminals for the transmitters of the HD4807T...and HD48V07T... series.
- RH% and AGND terminals for the transmitters of the HD4801T.. and HD48V01T.. series.
- RH% and AGND, Ta and AGND terminals for the transmitters of the HD4817T... and HD48V17T... series.
- DP and AGND, Ta and AGND terminals for the transmitters of the HD4877T... and HD48V77T... series.




HD48...series with RS485 output

Connect the instrument as shown in the below connection schemes, the power supply terminals are marked as +Vcc and GND.



Thanks to RS485 output, several instruments can be connected to form a network. The instruments are connected in a sequence through a shielded cable with twisted pair for signals and a third wire for the ground.





Line termination must be set at the two network ends. To polarize the line during nontransmission periods, resistor are connected between signal and power supply lines. The maximum number of devices that can be connected to the (Bus) line RS485 depends on the load characteristics of the devices to be connected.

The standard RS485 requires that the total load does not exceed 32 Unit Loads. The load of a HD485... transmitter is equal to ½ of the unit load.

If the total load is more than 32 unit loads, divide the net in segments and insert a signal repeater between one segment and the next one. At the beginning and at the end of each segment a line termination must be connected.

The instrument has a built in line termination that can be connected or removed through a short jumper placed next to the terminal block. If the instrument is the last or the first device of a network group, connect the termination placing the short jumper between the "RT" and "240 ohm" indications. If the instrument is not at the end of a network group, remove the termination placing the short jumper between the "RT" and "OPEN" indications






The cable shield must be connected to both line ends. The cable should have the following features:

- Characteristic impedance: 120 ohm
- Capacity: less than 50pF/m
- Resistance: less than 100 ohm/km
- gauge: 0,22 mm² (AWG24) at least.

The cable maximum length depends on baud rate and cable characteristics. Typically, the maximum length is 1200m. The data line must be kept separated from any power lines in order to prevent interferences on the transmitted signal. For connection to a PC, a RS232/RS485 or a USB/RS485 converter must be used. To operate with the MODBUS-RTU protocol be sure that the ADDRESS short jumper is between "ADDRESS" and "N=" indications.

Each transmitter of the network is univocally identified by an address. The address must be between 1 and 247. There must not be any other

transmitters connected with the same address. The address must be configured before connecting the instrument to the network. To set the instrument address use the software HD48STCAL downloadable from the website and the RS48 cable with built in USB/RS485 adapter. To configure the instrument it is necessary to move the ADDRESS short jumper between the "ADDRESS" and "N=0" indications to select the setup mode. After the configuration, move the short jumper back between the "ADDRESS" and "N=" indications.



HD48S... - Setting the RS485 communication parameters of the transmitter with a standard communciation program

Before connecting the transmitter to the RS485 network, an address must be assigned and the communication parameters be set, if different from the factory preset.

The parameters setting is performed as follows:

- If you have the RS48 cable, install the drivers in the PC.
- Connect the transmitter to a PC USB port using the cable RS48 (or alternatively through another USB/RS485 converter available, ensuring that their drivers are installed in the PC).
- Move the ADDRESS jumper between the sign "ADDRESS" and "N = 0" to select the configuration mode.
- Start a communication program such as Hyperterminal, and set the serial communication parameters as follows (the instrument is connected to a COM port type):

Baud rate: 115200 Parity: None Data Bits: 8 Stop Bits: 2

 Send the serial commands given in the following table to set the RS485 MODBUS parameters:

Command	Response	Description
MA nnn	&	Set RS485 address Ranging from 1 to 247 Preset on 1
MB n	&	Set RS485 Baud Rate n=0 ⇒ 9600 n=1 ⇒ 19200 Preset on 1 ⇒ 19200
MP n	&	Set RS485 transmission mode n=0 \Rightarrow 8-N-1 (8 data bits, no parity, 1 stop bit) n=1 \Rightarrow 8-N-2 (8 data bits, no parity, 2 stop bits) n=2 \Rightarrow 8-E-1 (8 data bits, even parity, 1 stop bit) n=3 \Rightarrow 8-E-2 (8 data bits, even parity, 2 stop bits) n=4 \Rightarrow 8-O-1 (8 data bits, odd parity, 1 stop bit) n=5 \Rightarrow 8-O-2 (8 data bits, odd parity, 2 stop bits) Preset on 2 \Rightarrow 8-E-1
MW n	&	Set receiving mode after RS485 transmission n=0 ⇒ Violates the protocol and gets in listen mode immediately after the transmission n=1 ⇒ Respects the protocol and waits 3.5 characters after the transmission Preset on 1 ⇒ Respects the protocol

• You can check the parameter setting and read the information of the instrument by sending the following serial commands:

Command	Response	Description
G0		Transmitter Model
G2		Serial number of the transmitter
G3		Firmware Version
G4		Firmware Date

Command	Response	Description
L1	Address	Read RS485 address
L2	Baud Rate (0,1)	Read RS485 Baud Rate 0 ⇒ 9600 1 ⇒ 19200
L3	Tx Mode (0,1,2,3,4,5)	Read RS485 transmission mode 0 ⇒8-N-1 1⇒8-N-2 2 ⇒8-E-1 3 ⇒8-E-2 4⇒8-O-1 5⇒8-O-2
L4	Rx Mode (0,1)	Read receiving mode after RS485 transmission 0 ⇒ Violates the protocol and gets in listen mode immediately after Tx 1 ⇒ Respects the protocol and waits 3.5 characters after Tx
PO	&	Ping

• When finished, reposition the ADDRESS jumper between the indications "ADDRESS" and "N =" to restore the MODBUS mode.

Reading of the measures with the MODBUS-RTU protocol when the instrument is in operating conditions (installed in a network)


In MODBUS mode, you can read the values measured by the instrument through the function code 04h (Read Input Registers). The following table lists the quantities available with the appropriate register address:

Address	Quantities	Format
0	Temperature in °C (x10)	16-bit integer
1	Temperature in °F (x10)	16-bit integer
2	Relative Humidity in % (x10)	16-bit integer
3	Dew Point in °C (x10)	16-bit integer
4	Dew Point in °F (x10)	16-bit integer
	State register	
	Bit $0 = 1 \Rightarrow$ temperature measurement error	
5	Bit $1 = 1 \Rightarrow$ humidity measurement error	16-bit integer
	Bit $2 = 1 \Rightarrow$ dew point calculation error	
	Bit $3 = 1 \Rightarrow$ configuration data error	

HD49... series

Follow the connection schemes shown below, the maximum load resistance that can be connected to each 4...20 mA output depends on the power supply Vcc applied, according to the relation:


 $\rm R_{Lmax}$ = (Vdc-12)/0.022, e.g. if Vdc=24Vdc the max load is $\rm R_{Lmax}$ =545 ohm.



Relative humidity probe calibration


The HD48... and HD49... transmitters are supplied factory calibrated and ready to use. If necessary, it is possible to calibrate the relative humidity sensor using the saturated salt solutions HD75 (75 %RH saturated salt solution) and HD33 (33 %RH saturated salt solution) by connecting the instrument to the PC and using the HD48TCAL software.

Fixing holes




Dimensions


TO series



TC series



TV series



ORDERING CODES:

HD48

Display
Blank = without display
L = with LCD display

Cable length (only for TC models)

2 = 2 m 5 = 5 m 10 = 10 m

Probe length

TO1 = 135 mm TO2 = 335 mm

TC1 = 135 mm TC2 = 335 mm TV = vertical wall mounting

Measuring range

Blank = standard range −20...+80 °C

E =extended range -40...+150 °C (except TV models)

Measured quantities

07 = Temperature

01 = Relative Humidity

17 = Temperature and Relative Humidity

77 = Temperature and Dew Point

Output

Blank = analog output 4...20 mA

V = analog output 0...10 Vdc

S = RS485 MODBUS-RTU output only

Note: the models with analog output have an output for each measured quantity.

HD49

Display

Blank = without display L = with LCD display

Cable length (only for TC models)

2 = 2 m 5 = 5 m 10 = 10 m

Probe length

TO1 = 135 mm **TO2 =** 335 mm

TC1 = 135 mm TC2 = 335 mm TV = vertical wall mounting

Measuring range

Blank = standard range -20...+80 °C

E =extended range -40...+150 °C (except TV models)

Measured quantities

07 = Temperature

01 = Relative Humidity

17 = Temperature and Relative Humidity

77 = Temperature and Dew Point

Example

HD4807TV: Wall mounting digital active temperature transmitter. Temperature range: -20...+80 °C. Analog output: 4...20 mA (-20...+80 °C). Probe working range -20...+80 °C. Power supply 18...40 Vdc or 24 Vac.

HD48V17ETC25: Digital active temperature and relative humidity transmitter, extended range. AlSl304 steel probe, diameter 14 mm and stem length 335mm, with 5m cable. Relative humidity range 0...100% RH, temperature range -40...+150 °C. Analog outputs: 0...10V (0...100 %RH) for RH and 0...10V (-40...+150 °C) for temperature. Probe working range -40...+150 °C. Power supply 18...40 Vdc or 24Vac.

Accessories

RS48: Cable for RS485 serial connection with buit-in USB/RS485 converter.

CP27: Connection/converter cable from COM AUX serial port to USB.

HD75: 75 %RH saturated solution for the verification of the relative humidity sensor.

HD33: 33 %RH saturated solution for the verification of the relative humidity sensor.

HD9008.31: Wall flange with cable gland to fix Ø14 mm probes.

Protection for humidity probes Ø 14, thread M12x1

 $\mbox{\bf P7}\!:$ 20 $\mu\mbox{m}$ PTFE protection. Operating temperature: -40...150 °C.

P8: PBT and 10 µm stainless steel grid protection. Operating temperature: -40...120 °C.



WARRANTY

The manufacturer is required to respond to the "factory warranty" only in those cases provided by Legislative Decree 6 September 2005 - n. 206. Each instrument is sold after rigorous inspections; if any manufacturing defect is found, it is necessary to contact the distributor where the instrument was purchased from. During the warranty period (24 months from the date of invoice) any manufacturing defects found will be repaired free of charge. Misuse, wear, neglect, lack or inefficient maintenance as well as theft and damage during transport are excluded. Warranty does not apply if changes, tampering or unauthorized repairs are made on the product. Solutions, probes, electrodes and microphones are not guaranteed as the improper use, even for a few minutes, may cause irreparable damages. The manufacturer repairs the products that show defects of construction in accordance with the terms and conditions of warranty included in the manual of the product. For any dispute, the competent court is the Court of Padua. The Italian law and the "Convention on Contracts for the International Sales of Goods" apply

TECHNICAL INFORMATION

The quality level of our instruments is the result of the continuous product development. This may lead to differences between the information reported in the manual and the instrument you have purchased. We reserves the right to change technical specifications and dimensions to fit the product requirements without prior notice.

DISPOSAL INFORMATION



Electrical and electronic equipment marked with specific symbol in compliance with 2012/19/EU Directive must be disposed of separately from household waste. European users can hand them over to the dealer or to the manufacturer when purchasing a new electrical and electronic equipment, or to a WEEE collection point designated by local authorities. Illegal disposal is punished by law.

Disposing of electrical and electronic equipment separately from normal waste helps to preserve natural resources and allows materials to be recycled in an environmentally friendly way without risks to human health.

