


HD 2020

ENGLISH

Our instruments' quality level is the result of the product continuous development. This can bring about differences between information written in this manual and the instrument that you have purchased. We cannot entirely exclude errors in the manual, for which we apologize.
Data, figures and descriptions contained in this manual cannot be legally asserted. We reserve the right to make changes and corrections without prior notice.

HD 2020 Acoustic calibrator



1. **ON-OFF** key: turns on and off the instrument. When you turn the instrument on, the display will switch on about two seconds later.
2. **SETUP** key: allows you to enter and scroll menu. To exit, press it repeatedly until you go back to the standard screen.
3. Display. When you turn the instrument on, it shows all segments on, then the sound pressure level (94 or 114dB) will appear in standard view.
4. Calibrator cavity for 1/2 inch microphones.
5. ▼ key: in standard mode, it selects 94dB and 114dB pressure levels alternately. In menu mode, it decreases the current value.
6. ▲ key : in standard mode, it selects 94dB and 114dB pressure levels alternately. In menu mode, it increases the current value.
7. Battery lid.

CERTIFICATO DI CONFORMITÀ DEL COSTRUTTORE

MANUFACTURER'S CERTIFICATE OF CONFORMITY

rilasciato da

issued by

DELTA OHM SRL STRUMENTI DI MISURA

DATA

DATE

2012/06/15

Si certifica che gli strumenti sotto riportati hanno superato positivamente tutti i test di produzione e sono conformi alle specifiche, valide alla data del test, riportate nella documentazione tecnica.

We certify that below mentioned instruments have been tested and passed all production tests, confirming compliance with the manufacturer's published specification at the date of the test.

Le misure effettuate presso un Laboratorio di Taratura Accredia sono garantite da una catena di riferibilità ininterrotta, che ha origine dalla taratura dei campioni di prima linea del Laboratorio presso l'istituto metrologico nazionale.

Measurements performed in an Accredia Calibration Laboratory are guaranteed by a uninterrupted reference chain which source is the calibration of the Laboratory first line standards at the national metrological institute.

Tipo Prodotto: Calibratore acustico


Product Type: Acoustic calibrator

Nome Prodotto: HD2020

Product Name:

Responsabile Qualità

Head of Quality



DELTA OHM SRL

35030 Caselle di Selvazzano (PD) Italy

Via Marconi, 5

Tel. +39.0498977150 r.a. - Telefax +39.049635596

Cod. Fisc./P.Iva IT03363960281 - N.Mecc. PD044279

R.E.A. 306030 - ISC. Reg. Soc. 68037/1998

INTRODUCTION

The HD 2020 sound level calibrator is a portable, battery operated sound source, suitable for sound level meters (portable and laboratory) and acoustic stations.

It allows calibrating 1/2" microphones with mechanical dimensions compliant with IEC 61094-1 ("Measurement microphones. Part 1: Specifications for laboratory standard microphones") and IEC 61094-4 ("Measurement microphones. Part 4: Specifications for working standard microphones").

The calibration pressure levels of 94dB and 114dB can be selected by the keypad. The 1000 Hz frequency cannot be changed.

If the microphone is absent or not inserted correctly into the calibrator cavity, the sound level will blink on the display.

To conserve battery life, the instrument is provided with an automatic power off function: if you leave the instrument on with open cavity, it switches off automatically after 30 seconds. If the cavity is closed and the microphone is inserted, the instrument switches off 5 minutes after turning on, provided that you don't press any key.

The calibrator display shows calibration pressure level, battery life, current date and time.

The internal clock allows to set up the validity period of calibration, expressed in years and months, starting from the date of adjustment: as soon as the time interval has elapsed, a blinking symbol alerts to make a new adjustment.

The HD 2020 calibrator advantages are:

- The 1000Hz frequency allows calibrating sound level meters with any weighting (LIN, A, B, ...), without applying any correction factor.
- The calibration sound pressure level is independent of atmospheric pressure: you don't need to adjust the value according to static pressure over a wide range of values.
- The HD 2020 calibrator can be conveniently used both in laboratory and in the field. The 114 dB sound level allows performing calibrations even in high background noise environments.
- Its simplicity of use allows even unqualified staff to employ it.
- The LCD makes easy to setup the calibrator, signals the calibration expiry and allows to control the level battery.

DISPLAY AND KEYPAD DESCRIPTION

The instrument keypad is composed of 4 keys.
Listed below are their main functions.



ON-OFF key

Press the ON/OFF key to turn on and off the instrument.

When you turn the instrument on, all the display segments are shown, for a few seconds ...



... an automatic test including battery power is performed and the instrument switches to standard mode.

Note: the display turns on 3 seconds after you press the ON/OFF key: meanwhile, the initial automatic test is performed.

AutoPowerOff function

The instrument is provided with an automatic power off function which switches off the instrument after about 5 minutes if the microphone is inserted in the cavity and you don't press any key.

If the cavity is open, the sound level blinks on the display: in this case the instrument switches off automatically after 30 seconds.

You cannot disable the AutoPowerOff function.



SETUP Key

The SETUP key allows entering and viewing the menu. To exit, press the SETUP key until you go back to the standard screen or press the key down for more than two second.

The menu shows:

- Current date and time in the format year, month, day, hour, minute, second.
- The interval between the calibration date and the expiry date in years and months.

You can set all these items: press SETUP to select it and use the arrow keys   to change it.

Press the SETUP key to confirm.

From the standard screen, press the SETUP key to view the current year:



Use the arrow keys to increase/decrease the value. Press the SETUP key to confirm and go to the current month:



Use the arrow keys to increase/decrease the value. Press the SETUP key to confirm and go to the current day:



Use the arrow keys to increase/decrease the value. Press the SETUP key to confirm and go to the current time:




Use the arrow keys to increase/decrease the value. Press the SETUP key to confirm and go to the current minute:



Use the arrow keys to increase/decrease the value. Press the SETUP key to confirm and go to the current second:



Whenever you press the arrow keys, seconds will be reduced to zero. Press the SETUP key to confirm and go to calibration section of the menu: the first triangle on the left turns on and the calibration year appear (this parameter cannot be modified by the user).



Pressing the SETUP key, calibration month appears (the parameter cannot be modified by the user).



(calibration month – first triangle)

Pressing the SETUP key, calibration day appears (the parameter cannot be modified by the user).



(calibration day – first triangle)

Pressing the SETUP key you can proceed to the expiration date of the calibration; the second triangle from the left switches on and the number of years of calibration validity appear. You can enter the number of years and months between the calibration date, which is entered by the calibration laboratory, and the expiry date. When the time interval expires, the triangle blinks to remind you that the calibrator needs a new adjustment.



(years of validity – second triangle)

Use the arrow keys to increase/decrease the value. Confirm with SETUP key and go on to the number of validity months.



(months of validity– second triangle)

Use the arrow keys to increase/decrease the value. Confirm with SETUP key and go back to standard view.



▲ Arrow key

In standard mode, it selects 94dB and 114dB sound pressure levels alternately. In menu mode, it increases the current value.



▼ Arrow key

In standard mode, it selects 94dB and 114dB sound pressure levels alternately. In menu mode, it decreases the current value.

CALIBRATION PROCEDURE

The HD 2020 can calibrate standard 1/2" microphones compliant with IEC 61094-1 and IEC61094-2. To calibrate the microphone, insert it deep into the cavity. The O-ring will offer some resistance.



During calibration the HD2020 can be held in vertical position or placed on a flat surface. While measuring, you should move neither the microphone nor the calibrator; make sure that the worktable doesn't transmit vibrations. A small misalignment of the microphone and calibrator axes is allowed.

- Before beginning to calibrate, you should make sure that the ambient noise level doesn't affect the calibration. After inserting the microphone into the cavity, with the sound level meter and the calibrator off, switch on the sound level meter and detect the unweighted ambient sound pressure level. If the measured level is below 78 dB, you can use both calibration sound levels (94 dB and 114 dB); if the level is between 78 dB and 98 dB you can use the 114 dB level only, while a sound level above 98 dB means that calibration is not possible.
- Press the ON/OFF key to switch on the instrument.
- Use the arrow keys to select the sound level: 94 dB or 114 dB.
- Make sure that the measurement value is not blinking on the display: this means that the microphone is not inserted correctly.
- Calibrate the sound level meter as per the procedure shown in the instrument manual.
- Apply the correction to the pressure level depending on the microphone (see the following chapter).
- Once calibration is complete, switch off the sound level meter and the calibrator and remove the microphone from the cavity.

The HD 2020 calibrator allows calibrating any sound level meter provided that it is equipped with a laboratory or working standard 1/2" microphone compliant with IEC 61094-01 and IEC 61094-4 standards.

Corrections depending on the microphone

The HD2020 calibrator generates a 94 dB (or 114 dB) sound pressure level referred to 20µPa. Working standard 1/2" microphones for sound level meters are manufactured to achieve flat frequency response in free or diffuse field, i.e. in a field of progressive plane waves propagating in the same direction as the microphone axis and in a field of sound waves coming from every direction, respectively. These propagation conditions are different from those in the calibrator cavity.

In free field, reflections due to the microphone alter the sound level by increasing the high-frequency cartridge effective sensitivity. Microphones optimized for free field measurements exploit this phenomenon to achieve flat frequency response even at very high frequencies. In these microphones, the sound level increase at 1 kHz corresponds to approximately 0.05 dB ÷ 0.20 dB. Therefore, when you calibrate a free field microphone, you must allow for this difference when you set a sound level 0.1 dB or 0.2 dB lower than the calibrator nominal one.

Microphones optimized for diffuse field measurements don't require corrections when calibrated in a closed cavity at 1 kHz instead.

LOW BATTERY INDICATION AND REPLACEMENT

The HD 2020 calibrator is provided with two batteries: a 9V alkaline battery that can be replaced by the user and a lithium buffer battery. The latter allows the date indicator and watch to work even without external battery: it must be replaced by a Delta Ohm authorized service centre.

The 9V battery power is constantly monitored:

- If the battery is fully charged, its symbol is off;
- If the battery is partially charged, its symbol blinks: please replace the battery as soon as possible;
- If the battery is uncharged and the instrument cannot work properly, its symbol is constantly on. When the battery is uncharged, the calibrator switches off in about 10 seconds.

To replace 9V batteries, switch off the instrument and open the lid at the bottom of the instrument. Replace the battery. Close the lid.

Date, time and calibration interval are stored if the buffer battery is charged.

The average life of the buffer battery depends on the external battery: if you use it, the average life of the internal battery is about 5 years.

Battery tips

- Remove the battery if the instrument is not to be used for an extended period. If the battery is low, replace it as soon as possible.
- Make sure that there is no loss of liquid.
- Use good quality sealed batteries (alkaline if possible).

CONSTRUCTION AND FUNCTIONING

Mechanical construction




Fig. 3 Calibrator mechanical construction (section).

Fig. 3 schematizes the HD 2020 calibrator structure (section). The battery compartment is on the right side of the case. The printed circuits and the electronics are over and under the battery compartment. The display and the keypad take up the higher part. The electro-acoustic transduction device is on the left and it consists of a wide cavity with a piezoceramic generator and a feedback sensor. The device emits the signal through the $\frac{1}{2}$ " microphone. An outer capillary hole balances the chamber static pressure protecting microphones from overpressure due to their insertion.

Control electronics

Fig. 4 shows the calibrator block diagram.




Fig. 4 Electronics block diagram.

The electronics consist mainly of an oscillator combining high stability and low distortion, as well as an RMS converter, the automatic gain control (AGC), the driver for the ceramic resonator and the feedback signal conditioning.

The RMS level of the signal provided by the sensor is compared with the factory set reference level; the difference adjusts the signal width generated by the oscillator and thus the acoustic signal generated by the piezoelectric transducer through automatic gain control.

The signal provided by the sensor slightly varies with the ambient temperature and the static pressure; the frequency of the signal provided by the oscillator is also stable in relation to ambient parameters.

INSTRUMENT STORAGE

Instrument storage conditions:

- Temperature: -25...+55°C.
- Humidity: below 90% RH without condensation.
- When storing the instrument, avoid:
 - High humidity.
 - Direct exposure to sunlight.
 - Exposure to high-temperature source.
 - Strong vibration.
 - Steam, salt and/or corrosive gas.

The instrument case is made of ABS: please use only compatible solvents to clean it.

FUNCTIONING AND OPERATING SAFETY

Authorized use

Please read carefully the specifications listed in the following chapter. You are allowed to use the instrument only in compliance with these instructions. Any other use is not authorized.

General safety instructions

This instrument is manufactured and tested in compliance with EN 61010-1 safety standard on electronic measuring instruments and it leaves the factory in perfect safety conditions.

Normal functioning and operating safety are guaranteed only if all usual and specific safety standards described in this manual are observed.

Normal functioning and operating safety are guaranteed only if climatic conditions are the same as described in the “specifications” chapter.

Use and store the instrument avoiding:

- Sudden change of the ambient temperature that may cause condensation.
- Inflammable or corrosive gases.
- Direct vibration or blows.
- Intense electromagnetic fields, static electricity.

If you carry the instrument from a cold to a hot environment, condensation may affect its functioning. In this case you should wait for the instrument temperature to reach the ambient temperature before using it again.

User obligations

The user must comply with the following standards and directives on the use of dangerous materials:

- EEC directives on safety in the workplace
- National legislation on safety in the workplace
- Safe working practices

SPECIFICATIONS

The HD 2020 calibrator complies with **IEC 60942-2003 Class 1** and **ANSI S1.40-1984**.

Coupling cavity:	for standard 1/2" microphones (12.7 ± 0.03 mm) according to IEC 61094-1 and IEC 61094-4
Frequency:	1000 Hz
Frequency tolerance:	1% in the range -10...+50°C and 10%...90%RH
Sound pressure level:	94.0 dB and 114.0 dB ±0.2 dB at 1kHz (referred to 101.3 kPa, 23°C ±3°C and 65% R.H.)
Reference conditions:	20°C, 50% RH, 101.3kPa, 10 mm ³ cartridge volume
Stabilization time:	10s
Total distortion:	<1%
Ambient condition influence	
Temperature and humidity influence:	< 0.3 dB in the range -10°C...50°C and 10%...90%RH
Static pressure influence:	< 0.1 dB in the range 65 kPa ... 108 kPa
Stability levels	
Short-term stability:	±0.03 dB
Stability after 1 year, normal use:	±0.1 dB
Operating conditions	
Working temperature:	-10 ... +50°C
Relative humidity:	≤90% R.H.
Storage temperature:	-25 ... +70°C
Microphone equivalent volume:	5 to 250 mm ³
Power supply:	9V alkaline battery IEC type 6LR61. 9V rechargeable batteries are also allowed.
9V battery autonomy:	48-hour continuous functioning with good quality alkaline batteries.
Automatic power off:	5 minutes – it cannot be disabled
Display	3½ digit LCD, battery symbol
Watch/date-indicator:	internal with 3V lithium buffer battery
Case material:	ABS
Dimensions:	53x43x83mm
Weight:	160g.
IP Protection degree	IP64
Effects of electromagnetic fields:	< 0.3 dB

ORDERING CODE

HD2020

The kit includes: HD2020 calibrator, one 9V alkaline battery, instruction manual and I-SO 9001 calibration report.

CONTENTS

INTRODUCTION	4
DISPLAY AND KEYPAD DESCRIPTION.....	5
CALIBRATION PROCEDURE	8
LOW BATTERY INDICATION AND REPLACEMENT	9
CONSTRUCTION AND FUNCTIONING.....	10
INSTRUMENT STORAGE	11
FUNCTIONING AND OPERATING SAFETY	12
SPECIFICATIONS.....	13
ORDERING CODE	14

WARRANTY

The manufacturer is required to respond to the "factory warranty" only in those cases provided by Legislative Decree 6 September 2005 - n. 206. Each instrument is sold after rigorous inspections; if any manufacturing defect is found, it is necessary to contact the distributor where the instrument was purchased from. During the warranty period (24 months from the date of invoice) any manufacturing defects found will be repaired free of charge. Misuse, wear, neglect, lack or inefficient maintenance as well as theft and damage during transport are excluded. Warranty does not apply if changes, tampering or unauthorized repairs are made on the product. Solutions, probes, electrodes and microphones are not guaranteed as the improper use, even for a few minutes, may cause irreparable damages.


The manufacturer repairs the products that show defects of construction in accordance with the terms and conditions of warranty included in the manual of the product. For any dispute, the competent court is the Court of Padua. The Italian law and the "Convention on Contracts for the International Sales of Goods" apply.

TECHNICAL INFORMATION

The quality level of our instruments is the result of the continuous product development. This may lead to differences between the information reported in the manual and the instrument you have purchased.

We reserves the right to change technical specifications and dimensions to fit the product requirements without prior notice.

DISPOSAL INFORMATION



Electrical and electronic equipment marked with specific symbol in compliance with 2012/19/EU Directive must be disposed of separately from household waste. European users can hand them over to the dealer or to the manufacturer when purchasing a new electrical and electronic equipment, or to a WEEE collection point designated by local authorities. Illegal disposal is punished by law.

Disposing of electrical and electronic equipment separately from normal waste helps to preserve natural resources and allows materials to be recycled in an environmentally friendly way without risks to human health.

CE RoHS

